



Puertas & Portones Automáticos, S.A. de C.V.

¡Nuestra pasión es la Solución!....

»BARRA DE PANICO HORIZONTAL AJUSTABLE Y REVERSIBLE ACABADO
PINTURA GRIS Ó ACERO INOXIDABLE MARCA ADS MOD. UL5000HP / UL5100HS.



PANIC EXIT DEVICE

MANUAL DE INSTALACION



(229) 461-7028



Versión Digital.



portonesautomaticos@adsver.com.mx
portonesautomaticos@prodigy.net.mx



RESIDENCIAL



COMERCIAL



INDUSTRIAL



MEMBER

IDA

International Door Association



V08.21




(229) 927-5107, 167-8080, 167-8007, 151-7529.

www.adsver.com.mx


MANUAL DE INSTALACION

A IDENTIFICATION OF PARTS




B TYPE OF INSTALLATION


A. SINGLE DOOR



B. DOUBLE DOOR WITH MULLION




C. DOUBLE DOOR WITHOUT MULLION




C DRILL HOLES

1. USE TEMPLATE ENCLOSED TO MARK DOOR FACE AND DRILL HOLES IN ACCORDANCE WITH THE DIAMETERS SUGGESTED
2. "B" LENGTH SHOULD BE MEASURED FROM THE CENTER OF CYLINDER HOLE TO THE END OF THE BODY

DRILL & TAP FOR (6) 1/4" x 20 MACHINE SCREWS FOR EXIT DEVICE AND DRILL & TAP FOR (3) 1/4" x 20 MACHINE SCREWS FOR ROLLER STRIKE.
OPTIONAL :
DRILL (6) 7/32" PILOT HOLES FOR SELF TAPPING MACHINE SCREWS OR WOOD SCREWS FOR EXIT DEVICE
DRILL (3) 7/32" PILOT HOLES FOR SELF TAPPING MACHINE SCREWS OR WOOD SCREWS FOR ROLLER STRIKE



INSIDE FACE OF THE DOOR




INSIDE FACE OF THE DOOR


MANUAL DE INSTALACION

D INSTALL KEY CYLINDER

If required or skip to step E




1. INSERT THE CYLINDER INTO THE HOLE ON THE DOOR
2. KEEP THE TAILPIECE HORIZONTAL
3. TIGHTEN THE SCREWS




E INSTALL BODY

1. REMOVE THE HEAD COVER AND THE SCREWS ON THE END COVER
2. ALIGN THE SCREW HOLES WITH THE HOLES ON THE DOOR
3. TIGHTEN THE SCREWS ON THE BODY AND THE LINING OF END COVER







F PUT ON BOTH HEAD AND END COVER



G INSTALL ROLLER STRIKE

1. WITH THE DOOR IN THE CLOSED POSITION MARK THE CENTERLINE OF LATCHBOLT ON DOOR JAMB.
2. PLACE ROLLER STRIKE ON DOOR JAMB. ALIGN CENTER OF ROLLER STRIKE WITH THE LATCHBOLT CENTERLINE MARK ON THE JAMB. THEN ALIGN THE OUTSIDE EDGE OF THE ROLLER STRIKE WITH THE OUTSIDE EDGE OF THE DOOR JAMB.


3. MARK THE CENTER OF THE 2 ADJUSTABLE SLOTTED HOLES AND DRILL 7/32\"/>
- 4. WITH ROLLER STRIKE IN FINAL POSITION, DRILL A 7/32\"/>



NOTE : INSTALL STRIKE SHIM UNLESS THE EXIT DEVICE HEAD COVER RUBS THE ROLLER STRIKE. THEN REMOVE THE STRIKE SHIM TO GAIN ADDITIONAL CLEARANCE.

MANUAL DE INSTALACION


H OPERATION TEST



AFTER INSTALLATION IS COMPLETE PRESS DOWN THE ACTUATING BAR TO MAKE SURE THE DOOR OPENS AND CLOSES/LATCHES CORRECTLY. MAKE ANY ADJUSTMENTS AS NEEDED.

NOTICE:

TO EXTEND THE LIFE OF THIS PANIC DEVICE, LOCK THE LATCH IN THE RETRACTED POSITION WHEN DOOR IS IN CONTINUOUS USE.



TO LOCK


HOLD ACTUATING BAR DOWN. TURN DOGGING DEVICE COUNTER CLOCKWISE WITH DOGGING WRENCH.


TO UNLOCK

HOLD ACTUATING BAR DOWN. TURN DOGGING DEVICE COUNTER CLOCKWISE WITH DOGGING WRENCH.



Puertas & Portones Automáticos, S.A. de C.V.
¡Nuestra pasión es la Solución!....

 (229) 461-7028

 portonesautomaticos@adsver.com.mx
portonesautomaticos@prodigy.net.mx



RESIDENCIAL



COMERCIAL



INDUSTRIAL



V08.21

(229) 927-5107, 167-8080, 167-8007, 151-7529.



www.adsver.com.mx